Technical Service Information



TSI-03-13-04

Date: July, 2003

Subject File: TRANSMISSION

Subject: Eaton Lightning Series Transmission, Codes 13GPB, 13GPC, 13GPD, 13GML, 13GMM, AND 13GMN, Clutch Access Cover Installation

Model: 8500 Model: 8600 Model: 9200i Model: 9400i

Model: 9900i Model: 9900ix

Unit Code: 13GPB
Unit Code: 13GPC
Unit Code: 13GPD
Unit Code: 13GML
Unit Code: 13GMM
Unit Code: 13GMN

DESCRIPTION

NOTICE

The information supplied herein has been furnished by the manufacturer and/or the supplier for use with its product. International Truck and Engine Corporation reprints this information based on representations made to the Company by the manufacturer and/or supplier and is not responsible for any errors or mishaps resulting from such errors or from any misuse of the product. Every user is urged to carefully follow the instructions which accompany the product.

Roadranger

Information Bulletin



Date: May 13, 2003 **FSUD:** 2003-AT-4114

Bulletin Type: Service

TAIB-0805

Topic: Lightning Series clutch access cover installation

Issue/Background: P/N 4304197

On Lightning series transmissions (FRLO(F)-1x410C) technicians have had questions regarding installation of the clutch access (hand-hole) cover.

Correction/Action:

<u>REMOVAL:</u> The access cover is easily removed by pulling it out of the clutch housing opening.

<u>INSTALLATION:</u> Follow the steps shown in the illustrations below to insure the cover is correctly locked in place.



<u>STEP 1</u> Squeeze the spring tabs together and remove from the slots.



<u>STEP 2</u> Rotate the spring down, install the cover with the tabs to the REAR as stamped on the cover then reinstall the spring tabs into the slots.

The material contained in this bulletin is product improvement information. Eaton Corporation is not committed to, or liable for, canvassing existing transmissions.